



Steam Quality Testing

Stay compliant with international standards HTM0101 and EN285 by testing your steam quality.

Whether your company or your specific products are required to meet international standards for steam sterilization, the Steam Quality Test Service will verify if you are yielding proper results.



In addition to Steam Quality Testing, visit our website to learn about our portfolio of Validation Service offerings

www.sterislifesciences.com

The Service consists of three (3) tests – Steam Dryness, Steam Superheat and Non-Condensable Gas – which can be performed over the course of three (3) days or one (1) day.

1

Steam Dryness Test

Measures the amount of moisture content in the steam.

2

Superheat Test

Measures the Superheat of the steam.

3

Non-Condensable Gas Test

Measures the amount of non-condensable gas, such as air or chlorine, present in the steam.



Trained service technicians perform the tests using a documented procedure based on HTM0101 and EN285 standards. The series of tests is performed three (3) times in order to verify repeatable results.

At the conclusion, you will receive a written report to show your compliance which summarizes the equipment that was tested and the results from each round of testing.



STERIS CORPORATION
5960 Heisley Road
Mentor, OH 44060, USA
T +1 800 444 9009

www.STERISLifeSciences.com

STERIS Offices Worldwide

Asia Pacific	+65 (0) 68 41 7677
Canada	+1 800 444 9009
Finland	+358 9 25851
France	+33 (0) 2 38 84 85 40
Germany	+49 (0) 221 466120
Italy	+39 (0) 2 21303 424
Latin America	+1 800 444 9009
Spain	+34 (0) 916 585 920
United Kingdom	+44 (0) 1256 840400

STERIS Life Sciences

For over 100 years, STERIS has been known as a global leader, trusted partner and solutions provider in the field of sterilization and contamination control. Today, STERIS continues building on this heritage by advancing the Science of sterilization, cleaning and infection control while offering Solutions that meet our Customers' needs and high standards. STERIS is dedicated to helping you enhance the Life of your patients and the life of your equipment. From Formulated Chemistries, to Capital Equipment, and to Parts and Services, STERIS Life Sciences is your Solutions provider.

© 2017 STERIS Corporation
All rights reserved

No part of this publication may be reproduced in any material form without the permission of STERIS Corp.